

IRIX Driver Installation

Addendum to 5515/5525/5575 PCI ATM Adapter Users Guide

Document No. UG05575-010, REVA

Print Date: October 7, 1997

Copyright Notice

© 1997 by Interphase Corporation. All rights reserved.

Printed in the United States of America, 1997.

This manual is licensed by Interphase to the user for internal use only and is protected by copyright. The user is authorized to download and print a copy of this manual if the user has purchased one or more of the Interphase adapters described herein. All copies of this manual shall include the copyright notice contained herein. No part of this manual, whether modified or not, may be incorporated into user's documentation without prior written approval of

Interphase Corporation
13800 Senlac
Dallas, Texas 75234
Phone: (214) 654-5000
Fax: (214) 654-5500

Disclaimer

Information in this manual supersedes any preliminary specifications, preliminary data sheets, and prior versions of this manual. While every effort has been made to ensure the accuracy of this manual, Interphase Corporation assumes no liability resulting from omissions, or from the use of information obtained from this manual. Interphase Corporation reserves the right to revise this manual without obligation to notify any person of such revision. Information available after the printing of this manual will be in one or more Read Me First documents included with this product.

THIS MANUAL IS PROVIDED "AS IS." INTERPHASE DISCLAIMS ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THOSE OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL INTERPHASE BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Trademark Acknowledgments

Interphase® and Syncard® are registered trademarks and CellView™, (i)chip™, ADSLWatch™, ADSLEye™, SynWatch™, SynEye™, FibreView™, and the Interphase logo are trademarks of Interphase Corporation.

Microsoft®, MS-DOS®, Windows®, and Windows NT® are registered trademarks of Microsoft Corp.

Novell® and NetWare® are registered trademarks of Novell, Inc.

Solaris® and NFS® are registered trademarks and SunOS™ and ONC™ are trademarks of Sun Microsystems, Inc. Sun is a trademark or registered trademark of Sun Microsystems, Inc.

SPARC® is a registered trademark of SPARC International, Inc. SPARCstation™ and UltraSPARC™ are trademarks of SPARC International, Inc., licensed exclusively to Sun Microsystems, Inc.

LattisCell™, EtherCell™, Bay Networks™, and SAHI™ are trademarks of Bay Networks, Inc.

UNIX® is a registered trademark in the United States and other countries, licensed exclusively through X/Open Company Ltd.

IBM® and OS/2® are registered trademarks and AIX™ and PowerPC™ are trademarks of International Business Machines Corporation.

HP-UX® is a registered trademark and Tachyon™ and Precision Bus™ are trademarks of Hewlett-Packard Company.

Intel® and Pentium® are registered trademarks of Intel Corporation.

TI® is a registered trademark of Texas Instruments.

Compu-shield® is a registered trademark of Stewart Connectors Systems, Inc.

Tundra® is a registered trademark and Universe™ is a trademark of Tundra Semiconductor Corporation.

Ethernet® is a registered trademark of Xerox Corporation.

DG/UX® and AViiON® are registered trademarks of Data General Corporation.

Apple® and Power Macintosh® are registered trademarks and Macintosh™, MacOS™, Mac™, AppleTalk™, and Open Transport™ are trademarks of Apple Computer, Inc.

NCR® is a registered trademark of NCR Corporation.

Silicon Graphics® is a registered trademark and SGI™, Indigo™, Indy™, Indigo²™, IRIX™, IRIS™, IRIS Indigo™, Challenge™, and Challenge M™ are trademarks of Silicon Graphics, Inc.

ALPHA™ is a trademark of Digital Equipment Corporation.

Gadzoox™ is a trademark of Gadzoox Microsystems, Inc.

Seagate™ and Barracuda™ are trademarks of Seagate Technology, Inc.

ST® is a registered trademark of AT&T.

SCO, The Santa Cruz Operation, SCO OpenServer, and UnixWare are trademarks or registered trademarks of The Santa Cruz Operation, Inc.

SUPERNET™ is a trademark of Advanced Micro Devices, Inc.

Cisco® is a registered trademark and Cisco Systems™ is a trademark of Cisco Systems, Inc.

Adobe® and Acrobat® are registered trademarks of Adobe Systems Incorporated.

CompactPCI® and PICMG® are registered trademarks of the PCI Industrial Computer Manufacturers Group.

Assistance

Product Purchased from Reseller

Contact the reseller or distributor if

- You need ordering, service or any technical assistance.
- You received a damaged, incomplete or incorrect product.

Product Purchased Directly from Interphase Corporation

Contact Interphase Corporation directly for assistance with this, or any other Interphase Corporation product. Please have your purchase order and serial numbers ready.

Customer Support

United States:	Telephone: (214) 654-5555
	Fax: (214) 654-5500
	E-Mail: intouch@iphase.com
United Kingdom:	Telephone: + 44 (0) 1869-321222
	Fax: + 44 (0) 1869-247720
France:	Telephone: + 33 (0) 1 41 15 44 00
	Fax: + 33 (0) 1 41 15 12 13
Asia/Pacific Rim:	Telephone: + 81 35423 6513
	Fax: + 81 3 5423 6511

World Wide Web

<http://www.iphase.com>

Anonymous FTP Server

<ftp.iphase.com>

Contents

ADDENDUM: IRIX Driver Installation

Overview	1
Before You Start.....	2
Driver Requirements.....	3
Configuring the Network Interface.....	3
Installing the Driver.....	6
Configuring the Adapter to the Network.....	9
Automating Startup and Shutdown	11
Verifying Driver Installation	14
Setting the European STM-1 mode.....	16
Index.....	17

Contents

IRIX Driver Installation

Overview

This addendum contains the procedures for installing the PCI ATM driver for IRIX™ version 6.4. The driver provides broadcast/multicast addressing, allowing you to run legacy LAN (Ethernet®, Token Ring, and FDDI) applications and protocols over an ATM network. Multiple emulated LANs (ELANs) are supported in that a single board can join up to four different ELANs and one IP over ATM segment simultaneously.

All references to *Users Guide* in this addendum are referring you to the *5515/5525/5575 PCI ATM Adapter Users Guide*.

The Interphase software supports the following:

- Three PCI ATM adapters per system
- User-Network Interface (UNI) 3.0/3.1 signalling specification for Switched Virtual Circuits (SVCs)
- Permanent Virtual Circuits (PVCs) based on RFC-1483
- ATM Forum LAN Emulation specification version 1.0
- Up to four LECs (LAN Emulation Clients) per adapter using both SVC and PVC communications
- One IP over ATM client (based on RFC-1577) per adapter using both SVC and PVC communications
- Optional Network Services per adapter
 - One LECS (LAN Emulation Configuration Server)
 - Up to eight LESs (LAN Emulation Servers)
 - One IP over ATM ARP server
- STM-1 European mode



CAUTION

Your ATM switch must be capable of supporting the UNI 3.0/3.1 signalling standard for SVCs. Some switch vendors allow the mixing of the two standards. Some vendors require that all ports be set to either UNI 3.0 or UNI 3.1. Check your switch documentation for the proper settings. The default setting for the PCI ATM adapter is UNI 3.0.

Before You Start

If any *Read Me First* documentation is in your installation kit, review it before installing the driver. It contains any changes and updates to this addendum since the printing date. Also, check for a **readme** file in the **IRIX_64bit** directory on the installation CD-ROM. If you are not thoroughly familiar with ATM networking, read the tutorial *ATM Technology Overview* in the *Users Guide*.

If you have any questions about the installation that are not answered in this addendum or in the *Users Guide* and supporting documentation, contact Interphase Customer Support. See the assistance information at the front of this addendum.

The basic procedures for installing the driver are:

- Verify driver requirements
- Initialize the network interfaces for the clients
- Install the ATM driver
- Enable and configure the clients with CellView™
- Automate the startup and shutdown

Driver Requirements

Installing the driver requires a system with the following:

- IRIX 6.4 (64 bit kernel only) operating system
- Root password
- 1.0 MB space in **/(root)** file system
- 6.0 MB space in **/usr** file system
- CD-ROM drive
- IP address, IP name, broadcast address, and netmask for each client to be enabled

In addition, the following information must exist:

- Major device number for the **ia** hardware driver. The default setting is 60.
- Major device number for the **li** software driver. The default setting is 61.

Configuring the Network Interface

It is recommended that the IRIX network interface be configured prior to running the Interphase install script. The configuration procedures in this section are specific to the IRIX operating system and not to the Interphase driver. The instructions are generic in nature, and your particular setup may vary slightly. This addendum assumes the person installing the driver is somewhat familiar with the administration of IRIX networking.

All the clients do not have to be initialized. You only need to configure the actual clients which are going to be used on the network. Additional clients, if needed, can be configured at a

later date without reinstalling the driver. For example, if you are going to use one LEC and the IP over ATM client, only two clients need to be initialized at this time.

To configure the IRIX network interface for the clients, do the following:

1. For each client being initialized (up to four LECs and one IP over ATM client per adapter), add the *<IP name>* and *<IP address>* to the hostname database file */etc/hosts*.

For example, a client with an IP address of *123.234.100.055* and an associated hostname of *irix-atm* is entered in the file as follows:

```
123.234.100.055 irix-atm
```



CAUTION

When other IP nodes reside on the host system (Ethernet for example), the IP address used for each ATM client must be a totally separate network segment. If the same segment is used, then routing and broadcast problems will occur as the network layer will assume that both devices are physically on the same segment. Also, do not assign more than one ATM client for an adapter to the same network segment.

-
2. Add the interfaces to the kernel by editing the file */etc/config/netif.options*.

Follow the directions provided in the file.

The mappings used by the ATM driver are as follows:

LECs:

*IP interface = (adapter number * 4) + client number*

IP over ATM clients:

IP interface = adapter number + 32

For example,

li0 = adapter 0, LEC 0

li1 = adapter 0, LEC 1

li2 = adapter 0, LEC 2

li3 = adapter 0, LEC 3

li4 = adapter 1, LEC 0

li5 = adapter 1, LEC 1

...

li11 = adapter 2, LEC 3

li32 = adapter 0, IP over ATM client

li33 = adapter 1, IP over ATM client

li34 = adapter 2, IP over ATM client

Each client represents an individual entity which must be added to the system. For example, when editing the **/etc/config/netif.options** file, look for blank *if<number>* variables such as:

```
:if<X>name=
```

```
:if<X>addr=
```

where *<X>* is the next available interface number.

Set the variables to their network interface values, then uncomment the lines by removing the colon, as shown in the following example:

```
if1name=li0
```

```
if1addr=irix-atm
```

where *li0* is from the above list of interface names for clients, and the *irix-atm* name is mapped to an IP address in the **/etc/hosts** file, edited in step 1.

3. Create the interface configuration file.

The system boot procedure performs an **ifconfig** on all network interfaces specified in the

/etc/config/netif.options file. This config uses command-line options contained in the file **/etc/config/ifconfig-<X>.options** where **<X>** is the interface number used in step **2**.

For example to create an ifconfig file for **if1**, the file name is **/etc/config/ifconfig-1.options** with the content your network requires, such as:

```
broadcast 123.234.100.0 \  
netmask 0xffffffff00 up
```

4. Repeat step **1** through step **3** for each network interface to be supported by the driver.

When the network interface is complete for all the needed clients, continue with the next section.

Installing the Driver

The driver can be installed prior to installing the adapter(s). Where feasible, however, it is recommended the adapter(s) be installed first. The CD-ROM included with the adapter contains all of the files required to install the driver. With the network interface completed as explained in the previous section, install the driver as follows:

1. Log in as **root**.

You must know the current password.

2. Check the available disk space by entering

```
df -k
```

There must be at least 1.0 MB of free space in the **/root** file system, and at least 6.0 MB of free space in the **/usr** partition.

3. If you are not sure which operating system is installed on your machine, enter the command,

```
uname -sr
```

The machine must be running IRIX version 6.4. with a 64-bit kernel.

4. Determine whether you need to change the defaults for the installation script.

The variables are as follows:

Variable	Command	Description	Default
BINDIR	-b (<i>path</i>)	Directory for binaries	<code>/usr/sbin</code>
CFGDIR	-c (<i>path</i>)	Directory for config files	<code>/etc/config</code>
MANDIR	-m (<i>path</i>)	Directory for man pages	<code>/usr/share/catman/a_man/cat1</code>
IAMAJ	-i (<i>num</i>)	Major device number for ia hardware driver	60
LIMAG	-l (<i>num</i>)	Major device number for li software driver	61
IUSR	-u usr	Install 'user'	root
IGRP	-g grp	Install 'group'	sys

You can change the defaults in either of two ways:

- Permanently change the value of a variable by editing the **inatm** installation script.
- Temporarily override the default for one or more variables by using command-line options.

For example, if you want to change the install script permanently to place the binary utility files in **/bin** instead of the default **/usr/sbin**, you have to edit the BINDIR variable in the install script to read:

```
BINDIR = /bin
```

To override the same default as a one-time substitution during the current installation, use the command-line option

```
inatm -b /bin
```

Additional options are separated with a space. For example, if a value of 80 is needed for the IMAJ variable, in addition to the BINDIR setting above, the multiple commands would be

```
inatm -b /bin -i 80
```

5. Insert the CD-ROM in the local drive and enter,

```
cd /CDROM/IRIX_64bit
```

6. Run the installation script to install the driver.

- a. Enter the command:

```
./inatm [option(s)]
```

where **[options(s)]** is the command-line options, if needed, as explained in step 4 on page 7.

- b. If an existing PCI ATM driver is detected on your machine, the installation script detects it and prompts you to remove it.

Enter **yes** if this occurs.

- c. You are prompted to confirm the parameters for installing the driver.

Enter **yes** at the prompt. Otherwise, enter **no** and repeat this procedure beginning with step 4 on page 7.

The installation script begins to execute and should run to completion without any interrupts. When complete, a prompt appears to reboot the machine.

7. Enter **yes** at the prompt.

Continue the installation with the procedures in the next section.

Configuring the Adapter to the Network

The Interphase CellView utility is used to enable and configure the clients to the network. See *CellView Utility* in the *Users Guide* for details on how to use the utility.

With the driver installed as described in the previous section, do the following:

1. If the adapter(s) are not installed, halt the machine and install the adapters at this time.
2. If not done in the previous step, reboot the machine.
3. Configure the adapter(s) to the network with the Interphase CellView utility by entering the command:

cellview

The main CellView dialog appears with a listing for each PCI ATM adapter installed in the machine.

4. If more than one adapter is installed in the machine, move the highlight to the adapter to be configured.
5. Select **Setup** and check the Signalling parameters.
All settings must conform to the capabilities of your ATM switch.

6. Enable and configure the clients that were initialized in the previous sections.

a. From the Setup dialog, select the **LEC** tab and configure the LECs.

Clarification Note: The CellView utility denotes the four LECs on an adapter as LEC 1 – LEC 4. During installation of the driver, the four clients are denoted as LEC 0 – LEC 3 (see step 2 on page 4).

b. From the Setup dialog select the **1577** tab, if needed, to configure the IP over ATM client and the ARP server (optional).

7. If the LECS and the LESs are to be on this machine, enable the LECS and the quantity of LESs as required.

At initial installation, the dialogs for the servers are disabled and their tabs do not appear in the Setup or Statistics menus. To activate the dialogs,

a. From the main CellView dialog, select **Global**.
The Application dialog appears.

b. Turn on Enable Advanced Settings by clicking the adjacent box or button, whichever is available in your dialog.

The feature is enabled when a check mark appears in the box or when the button is depressed.

c. Select **OK**.

The tabs for the LECS and the LESs should now be visible in the Setup and Statistics routines.

8. When complete, exit the CellView utility.

Continue the installation with the procedures in the next section.



CAUTION

All configuration data for CellView is stored in the file `/etc/atm/cvconf` for which an on-line man page is available. You are strongly encouraged to use the CellView utility to modify the parameters instead of editing them manually. If the parameters get out of sync, the driver may not work properly.

If for some reason the CellView utility will not run on your system, there are command-line utilities (such as `lec`, `les`, and `lecs`) which can modify the software currently running. However, these commands do not change the permanent settings in the `cvconf` file. The effects of these commands are lost when the machine is turned off or restarted. Whatever the case, do not mix the running of command-line and CellView utilities. Use one method consistently or unpredictable results may occur.

Automating Startup and Shutdown

The UNI signalling application must be started after the hardware device drivers have been loaded by the kernel. The application can be started manually after bootup, or the start procedure can be automated using the startup script provided with the installation software. You can add both startup and shutdown commands to the `/etc/init.d/network` file.

To automate the startup and shutdown, edit the `/etc/init.d/network` file as follows:

1. Set the LEC startup by adding the following script ahead of the double semicolon (;;) that terminates the case **start** statement:

```
# ATM/LEC startup
if $IS_ON atmcv && test -x /usr/sbin/cvconf; then
  /usr/sbin/cvconf
fi
```



NOTE

The paths to the `lec`, `sigd_start`, and `iadump` files referred to in this section must match the paths specified during the driver installation (the `-b` command-line option). The paths to `lec`, `sigd`, and `iadump`, if changed from the install script's default (`/usr/sbin/`), must be changed in the following examples, and also in the scripts: `sigd_start` and `sigd_stop`.

The `inatm` install script creates the `/etc/config/atmcv` file with the contents set to `on`. This file is used by the `$IS_ON` test created above. To disable the configuration of the LANE clients at boot time, change the contents of the file to `off`. This change mandates that you configure each client manually after every boot or reboot.

2. Set the `sigd` startup by adding the following command lines to the end of the case `start` statement:

```
# ATM/SIGD startup
if $IS_ON atmsigd && test -x /usr/sbin/sigd_start; then
  /usr/sbin/sigd_start
fi
```

The `inatm` install script creates the `/etc/config/atmsigd` file with the contents set to `on`. This file is used by the `$IS_ON` test created above. To disable startup of the signalling application at boot time, change the contents of the file to `off`. This change mandates that you start the `sigd` application manually after every boot or reboot.

3. Shut down the system.

Most systems do not provide a hardware reset during a reboot. If the hardware is not reset during a reboot, the board remains active, and the kernel PANICs on receipt of the first packet.

You can provide this hardware reset by adding the following script ahead of the double semicolon (;;) that terminates the case **stop** statement:

```
# ATM/LANE shutdown
if $IS_ON atmdown && test -x /usr/sbin/iadump; then
/usr/sbin/iadump shutdown
fi
```



CAUTION

If you do not add a shutdown command and the *Kernel PANIC* occurs, the only way to bring the workstation back up is to turn the power off, and then back on again.

The **lane** install script creates the **/etc/config/atmdown** file with the contents set to **on**. This file is used by the **\$IS_ON** test created above. To disable this hardware reset during shutdown, change the contents of the file to **off**. This change mandates that you reset the hardware manually prior to a reboot (or requires a power cycle before booting).

4. Reboot the system.

To activate the adapter and driver, do the following:

- a. Click the desktop manager's System Restart function, or enter

```
/etc/reboot
```

- b. Watch the console for messages and/or errors starting with **IASG** as the system reboots.

These messages are copied to the system log file **/var/adm/SYSLOG**, where you can access them if needed.

The installation of the driver for the PCI ATM adapter is complete.

See the next section if you wish to verify the installation.

Verifying Driver Installation

For a client to have any form of communication with a server,

- The switch must be configured correctly
- The client must be enabled and configured correctly
- Signalling must be up and running
- The adapter must be assigned a network prefix
- At least one LES must be present on the network

An application program does not have to be running in order to check these items. At bootup of the endstation, certain systems communications must take place between the client and the server (through the switch) in order for the client to log on to the network. Use the Statistics routines in the Interphase CellView utility to monitor this traffic as well as for checking a few other essential items.

If you find an item in error, or you suspect something is wrong with your setup, see *Troubleshooting* in the *Users Guide*. If you cannot resolve the problem with the information in the *Users Guide* and supporting documentation, contact Interphase Customer Support at the nearest location listed in the front of this addendum.

To perform a quick check of the operating statistics for an adapter, do the following:

1. Run the CellView utility by entering the command:

cellview

See *CellView Utility* in the *Users Guide* for detail operating instructions.

2. When the main CellView dialog appears, select an adapter in the listbox; that is, if more than one adapter is installed in the machine.

3. Select **Stats**.

The Signalling dialog appears for the selected adapter.

- All three graphical LEDs in the Signalling State box should be green in color
- The three text fields in the State Detail box should read similar to:

ILMI: ILMI Registered

QSAAL: Data transfer ready

Signalling: Signalling Ready

- There should be some traffic numbers in the Signalling Statistics box for both Frames In and Frames Out

4. Select the **AAL5** tab.

- All six graphical LEDs in the SONET box should be green in color
- There should be some traffic numbers in the AAL5 Statistics box

5. If at least one LEC on the adapter is enabled, select the **LEC** tab.

- a. Select the tab for an enabled LEC.

- The LEC graphical LED should be green in color
 - There should be some traffic numbers in the Tx Packets and Rx Packets fields of the display boxes
- b.** Repeat the above step for all enabled LECs.
- 6.** If the IP over ATM client is enabled, select the **1577** tab.
- The **1577** graphical LED should be green in color
 - There should be some traffic numbers in the **1577** Statistics fields
- 7.** If more than one adapter is installed in the machine, repeat step **2** through step **6** for each additional adapter.

When complete, exit the CellView utility.

Setting the European STM-1 mode

To configure the adapter for European STM-1 mode edit the file `/var/sysgen/master.d/li` as follows:

1. Locate the line

```
int ia_stm = 0;
```

2. Set the `ia_stm` variable to 1 instead of zero:

```
int ia_stm = 1;
```

3. Run the command,

```
/etc/autoconfig
```

4. Reboot the system.

Index

When using this index, keep in mind that a page number indicates only where referenced material begins. It may extend to the page or pages following the page referenced.

A	
AAL5 statistics	15
<i>autoconfig</i> command	16
B	
broadcast address	3, 6
C	
case <i>start</i> statement	11, 12
case <i>stop</i> statement	13
caution	
ATM switch requirements	2
command-line utilities	11
kernel PANIC	13
network segments	4
CellView utility	
configure clients	9
LES/LECS dialogs	10
verify installation	15
client/server communications	14
D	
disk space available	6
disk space requirements	3
driver removal	8
F	
files	
/etc/atm/cvconf	11
/etc/config/atmfv	12
/etc/config/atmfvdown	13
/etc/config/atmsigd	12
/etc/config/ifconfig-X.options	6
/etc/config/netif.options	4, 5, 6
/etc/hosts	4, 5
/etc/init.d/network	11
/var/adm/SYSLOG	14
/var/sysgen/master.d/li	16
H	
hostname	4
I	
<i>ia</i> hardware driver	3, 7
IASG messages	14
<i>ifconfig</i> command	5
<i>inatm</i> install script	7, 12
command	8
command-line options	7
IP address	3, 4
IP interface formula	4
IP over ATM clients	
enable	10
initialize	4
verify	16
L	
LANE clients (LECs)	
enable	10
initialize	4
verify	15
<i>lane</i> install script	13
<i>li</i> software driver	3, 7
N	
netmask	3, 6
network interface	3
P	
PANIC (kernel)	13
permanent virtual circuits (PVCs)	1

R
readme file 2
reboot command 13
RFC-1483 1
RFC-1577 1

S
signald startup 12
signalling statistics 15
STM-1 mode 16
switch requirements 2
switched virtual circuits (SVCs)..... 1

U
uname command..... 7
UNI 3.0/3.1 2